Approach 1: Gathering the data and sending the results to: Google Spreadsheet on your Google Drive.

A core part of the "Internet of Things" movement is the idea of devices that gather data and send it to the Internet. That data is then acted on or observed for later. It's a simple concept and has been going on for a while but lately it's been getting cheaper and easier to do.

## **Google Spreadsheets**


You can output data to a Google Spreadsheet application. You will need to setup OAuth with Google, and create a JSON file. The steps are as mentioned below:

## Using OAuth2 for Authorization (OAuth Credentials)

- 1. Head to Google Developers Console and create a new project (or select the one you have.)
- 2. Under "API & auth", in the API enable "Drive API".



3. Go to "Credentials" and choose "New Credentials > Service Account Key".



4. You will automatically download a JSON file with this data.



5. This is how this file may look like:

```
{
    "private_key_id": "2cd ... ba4",
    "private_key": "----BEGIN PRIVATE KEY----\nNrDyLw ... jINQh/9\n----END PRIVATE
KEY----\n",
    "client_email": "473 ... hd@developer.gserviceaccount.com",
    "client_id": "473 ... hd.apps.googleusercontent.com",
    "type": "service_account"
}
```

You'll need *client\_email* and *private\_key*.

6. Install oauth2client:

```
pip install --upgrade oauth2client
```


7. Depending on your system setup you may need to install PyOpenSSL:

```
pip install PyOpenSSL
```

You will want to store the generated **JSON** file in the **MiniWeatherStation.py** folder. One thing you will need to is open up that **OAuth JSON** file and look for "**client\_email**". It should look like this:

"client\_email": "1985453359310-asdlkjried8ss98eeEic@developer.gserviceaccount.com",

Take note of that email address value and go to your Google spreadsheet in a web browser. Using the **File** -> **Share...** menu item share the spreadsheet with **read access** to the email address found above.



8. Next, open up the WeatherStationmod.py file and edit:


sudo nano WeatherStationmod.py

Replace the GDOCS\_OOAUTH\_JSON value with the name of your JSON file you downloaded. Set the GDOCS\_SPREADSHEET\_NAME with the name of your sheet. Save it.


## Type in:

sudo python WeatherStationmod.py

If all your information is correct, it will start running and adding rows to your spreadsheet every 10 seconds.



## Code:



```
try:
json key = json.load(open(oauth key file))
credentials=SignedJwtAssertionCredentials(json key['client email'],json key['private key'],
['https://spreadsheets.google.com/feeds'])
gc = gspread.authorize(credentials)
worksheet = gc.open(spreadsheet).sheet1
return worksheet
except Exception as ex:
print 'Unable to login and get spreadsheet. Check OAuth credentials, spreadsheet name, and
make sure spreadsheet is shared to the client email address in the OAuth .json file!'
print 'Google sheet login failed with error:', ex
sys.exit(1)
sense = SenseHat()
sense.clear()
                                                                 {0}
          'Logging
print
                                                                                      {1}
                         sensor
                                     measurements
                                                                          every
seconds.'.format(GDOCS SPREADSHEET NAME, FREQUENCY SECONDS)
print 'Press Ctrl-C to quit.'
worksheet = None
while True:
# Login if necessary.
if worksheet is None:
worksheet
                                              login open sheet(GDOCS OAUTH JSON,
GDOCS SPREADSHEET NAME)
```

```
# Attempt to get sensor reading.
      temp = sense.get temperature()
      temp = round(temp, 1)
      humidity = sense.get humidity()
      humidity = round(humidity, 1)
      pressure = sense.get pressure()
      pressure = round(pressure, 1)
      # 8x8 RGB
      # sense.clear()
      info = 'Temperature (C): ' + str(temp) + 'Humidity: ' + str(humidity) + 'Pressure: ' +
str(pressure)
sense.show message(info, text colour=[255, 0, 0])
      # Append the data in the spreadsheet, including a timestamp
      try:
            worksheet.append row((datetime.datetime.now(), temp,humidity,pressure))
      except:
            # Error appending data, most likely because credentials are stale.
            # Null out the worksheet so a login is performed at the top of the loop.
            print 'Append error, logging in again'
            worksheet = None
            time.sleep(FREQUENCY SECONDS)
            continue
      # Wait 30 seconds before continuing
      print 'Wrote a row to {0}'.format(GDOCS SPREADSHEET NAME)
      time.sleep(FREQUENCY SECONDS)
```